

## 3/8" DR IMPACT SOCKET & DEEP IMPACT SOCKETS



### 3/8" DR METRIC IMPACT SOCKETS



- Chrome molybdenum
- Flat drive technology
- Manufactured to DIN standards

Model No.	Size	Model No.	Size	Model No.	Size	Model No.	Size
SP22707	7mm	SP22711	11mm	SP22715	15mm	SP22719	19mm
SP22708	8mm	SP22712	12mm	SP22716	16mm	SP22720	20mm
SP22709	9mm	SP22713	13mm	SP22717	17mm	SP22721	21mm
SP22710	10mm	SP22714	14mm	SP22718	18mm	SP22722	22mm



### 3/8" DR SAE IMPACT SOCKETS



- Chrome molybdenum
- Flat drive technology
- Manufactured to DIN standards

Model No.	Size	Model No.	Size	Model No.	Size	Model No.	Size
SP22751	1/4"	SP22754	7/16"	SP22757	5/8"	SP22760	13/16"
SP22752	5/16"	SP22755	1/2"	SP22758	11/16"	SP22761	7/8"
SP22753	3/8"	SP22756	9/16"	SP22759	3/4"		



### 3/8" DR METRIC DEEP IMPACT SOCKETS



- Chrome molybdenum
- Flat drive technology
- Manufactured to DIN standards

Model No.	Size	Model No.	Size	Model No.	Size	Model No.	Size
SP22807	7mm	SP22811	11mm	SP22815	15mm	SP22819	19mm
SP22808	8mm	SP22812	12mm	SP22816	16mm	SP22820	20mm
SP22809	9mm	SP22813	13mm	SP22817	17mm	SP22821	21mm
SP22810	10mm	SP22814	14mm	SP22818	18mm	SP22822	22mm



### 3/8" DR SAE DEEP IMPACT SOCKETS



- Chrome molybdenum
- Flat drive technology
- Manufactured to DIN standards

Model No.	Size	Model No.	Size	Model No.	Size	Model No.	Size
SP22851	1/4"	SP22854	7/16"	SP22857	5/8"	SP22860	13/16"
SP22852	5/16"	SP22855	1/2"	SP22858	11/16"	SP22861	7/8"
SP22853	3/8"	SP22856	9/16"	SP22859	3/4"		