

### NOID LIGHT KITS

Model No.	Description
SP71050	• 6pc Noid light kit
SP71052	• 10pc Noid light kit

- Check fuel injector signal faults fast
- Simply disconnect injector harness and plug in noid Light
- Easy to use and fits a wide variety of injector harnesses
- Compatible with: GM PFI, FORD TBI, GEO TBI, BOSCH PFI, GM TBI, GM SCPI



### SIMPLY DISCONNECT INJECTOR HARNESS AND PLUG IN NOID LIGHT

Model No.	Description
SP66150	Suits Bosch Port fuel Injection harness with round pins
SP66151	Suits GM Port fuel Injection harness with flat pins
SP66152	Suits GEO Throttle body Injection harness with flat pins
SP66153	Suits GM Throttle body Injection harness with large round pins
SP66154	Suits GM SCPI Throttle body Injection harness with large round pins
SP66155	Suits Ford TBI Throttle body Injection harness with large round pins



### A/C & FUEL LINE QUICK DISCONNECT SET

Model No.	Description
SP64050	<ul style="list-style-type: none"> <li>• Easy Clip Over Design</li> <li>• Simple Push Under Fitting until Hose Releases</li> <li>• 5/16", 3/8", 1/2", 5/8", 3/4" &amp; 7/8"</li> </ul>



### FUEL LINE DISCONNECT TOOL

Model No.	Description
SP64051	<ul style="list-style-type: none"> <li>• Fits E-3/8", F-5/16" Fuel Lines</li> <li>• Release Locking coupling on 5/16" &amp; 3/8" Fuel lines</li> </ul>



### AC & FUEL LINE DISCONNECT KIT

Model No.	Description
SP64052	<ul style="list-style-type: none"> <li>• Comprehensive set of tools for decoupling Automotive Air Conditioning hoses and fuel lines</li> <li>• Offset Design with Spring loaded action allows one handed operation</li> <li>• Suitable for a wide variety of Vehicles</li> <li>• Colour coded and Supplied in a Carry Case</li> </ul>



### STEEL LINE STOPPER KIT

Model No.	Description
SP71100	<ul style="list-style-type: none"> <li>• Prevents fluid leaks and contamination during service</li> <li>• Use with all automotive fluids</li> <li>• <b>Suitable for:</b></li> <li>• Fuel Rails and Lines</li> <li>• Flare Type Steel Brake, Fuel &amp; AC Lines</li> <li>• Banjo Fittings on Brake, Power Steering &amp; Transmission Cooler Lines</li> <li>• Installs in seconds</li> </ul>

