



USER MANUAL



SP81400

**BLUETOOTH
SPEAKER & WORK
LIGHT**

**RETAIN THESE INSTRUCTIONS
AND ATTACH RECEIPT TO
MANUAL FOR FUTURE
REFERENCE**

NOTE: Proof of purchase must be retained by the customer as it will be required in the event of a claim under warranty.



AFTER SALES SUPPORT:

WWW.SPTOOLS.COM

AUSTRALIA: Visit the website's **contact page** to get in touch with your local service department.

INTERNATIONAL: Use the **county selector** to get in touch with your service department in your country or region.



IMPORTANT

ALL PERSONS WHO ARE TO USE THIS EQUIPMENT MUST THOROUGHLY READ AND UNDERSTAND THIS INSTRUCTION MANUAL PRIOR TO OPERATION.

CONTENTS

Introduction	2
Features	2
Specifications	2
Scope of delivery	2
Operating instructions	3
Warranty Details	4

INTRODUCTUION

Features

1. Durable ABS construction
2. Long range 5.0 Bluetooth capability
3. 2 x Speakers 6W total
4. 4400mAh Rechargeable Battery, can also be used as power bank
5. COB LED Light with high, low, brightness control
6. Carabiner, so unit can be hung for convenience
7. IP65 Dust proof / Water Resistant (connection cap must be in place)
8. Strong magnetic base and end, for secure positioning

Specifications

1. 10W COB LEDS High: 800 Lumen; Low: 400 Lumen
2. Sound output 6W (2 x 3W Speakers)
3. USB to USB-C Charging cable, 80cm
4. Battery: 3.7V, 4400mAh
5. Lighting run time: 5hours (High Mode); 8hours (Low Mode)
6. Charging Time: 4-5Hours via USB Cable
7. Size: 206mm long x 76mm Diameter
8. Weight: 0.59Kg (Includes battery)

Scope of delivery

1. Main unit
2. Carabiner (quick release clip)
3. Charge cable
4. Clam shell storage case
5. User Manual

Operating instructions

Charging

Lift the weather proof rubber flap at the magnetic end of the main body.

Connect the USB-C cable end (smallest end) into the main unit, then connect the larger USB cable end to any suitable USB outlet. This could be, your computer, vehicle, phone charger or portable power bank, etc.

Once connected the battery charge indicator lights will illuminate and show the charge level. When fully charged all 4 lights will show solid.

Be sure to reinsert the weather cover before taking the unit into any wet, or dirty environments.

Bluetooth connection

First ensure your phone or other Bluetooth enabled device has its Bluetooth turned on (see Settings).

Then press and hold the centre button (for 3 seconds), on end of main body.

The unit will respond with the words "Power on, Bluetooth" then shortly afterwards "Bluetooth connected". The initial pairing may not occur automatically. In which case open the Bluetooth on your device and manually select the device connection. Once paired it will automatically connect whenever the Speaker is powered on.

On unit the volume can be adjusted by the + or – buttons and track selection made via the forward and reverse buttons.

To turn off press and hold the centre button (for 3 seconds), the unit will respond with the words "Power Off"

Light Operation

The ON / OFF button for the light is located adjacent to the COB LED's

Warning: Do not look at the LED's, face the unit away from you and press the button once to turn ON Low lighting, press the button once again for High lighting and a third time to turn the light OFF.

LIMITED WARRANTY

This Limited Warranty applies only to new products* distributed by SP Tools Pty Ltd ("SP Tools"). It is a condition of this Limited Warranty Policy that the purchaser read the owner's manual for the product and only use the product to the extent or for the purposes stated therein. The purchaser must also ensure that all servicing requirements are completed as listed in the owner's manual (said servicing is at the owner's expense). We recommend that all servicing is completed by an authorised service agent and that records of said servicing are retained by the purchaser as proof in the event of a warranty claim.

Whilst the owner's manual, packaging, and/or other documentation supplied with SP Tools' products may provide details in respect of a Limited Warranty, the terms set out herein supersede these matters, and this Limited Warranty applies in their place. This warranty is no less advantageous than otherwise described in such other documentation.

SP Tools agrees, subject to the terms and conditions specified below, to repair or replace at SP Tools' cost, the product purchased by you when the product does not perform in accordance with its specifications during the limited warranty period, due to any fault in manufacturing, materials and/or workmanship. SP Tools is not liable to repair or replace products that the purchaser uses in a manner that is inconsistent with the owner's manual or in the circumstances set out in paragraphs 1.1 – 1.7 below.

The benefits to the purchaser under this warranty are in addition to other rights and remedies under the *Competition and Consumer Act 2010* (Cth). The limited warranty period, within which a defect in the product must appear, commences from the date of purchase and ceases on expiration of the specified term below.

THE LIMITED WARRANTY PERIOD

- SP Speciality Tools – 12 Months



THE PURCHASERS ATTENTION IS DRAWN TO THE FOLLOWING

To the extent permitted by law and subject to this Limited Warranty, and as part of the terms of the sale of the equipment or part thereof: SP Tools shall not be liable for any form of loss, damage, cost, injury or harm of any kind (whether direct, indirect, special or consequential) howsoever arising from the use or supply of the equipment to the purchaser.

EXCLUSIONS TO LIMITED WARRANTY POLICY

This Limited Warranty will not apply where the equipment or any part thereof:

- 1.1 Fails due to an accident (including liquid spillage), abuse, misuse, neglect or normal wear and tear;
- 1.2 Has been used in a manner other than for which it was originally designed;
- 1.3 Has been tampered with or is otherwise than as supplied by SP Tools;
- 1.4 Where any damage, malfunction or other failure of the equipment or any part thereof resulted directly or indirectly from unauthorized persons, adjusting or failing to adjust any part requiring normal maintenance and service (examples include adjustment of tappets, air filter maintenance, lubrication and tightening of screws nuts and bolts);
- 1.5 Malfunctions due to the use of defective or incompatible accessories;
- 1.6 Is damaged by lightning or thunderstorm activity; or
- 1.7 Has been transported to a country where no authorised Service Agents exist.

CLAIMING WARRANTY

This Limited Warranty may be claimed on in the following manner:

- 2.1 In order to make a claim under this Limited Warranty, the purchaser must deliver the equipment or any part thereof to an SP Tools authorised repair agent and pay all costs of transportation and all costs incidental to making a claim under this Limited Warranty. The purchaser must first contact SP Tools (contact details described above) and request the delivery address of an SP Tools authorised repair agent.
- 2.2 The purchaser must deliver to the repair agent written reasons why the purchaser considers that the purchaser has a claim under this Limited Warranty and must provide all necessary details, including:
 - The place, date and from whom the unit or part was purchased.
 - The unit or part involved, Model and Serial Number.
 - The defect, malfunction or failure in respect of which the claim is being made.
 - Proof of service of the unit or part (if applicable)
 - Proof of purchase in respect of the unit or part.
- 2.3 If the Limited Warranty claim is valid, the repair agent will carry out repairs and return the product at no charge to the purchaser. These repairs are limited to the Limited Warranty fault identified and as such will not include any other faults due to misuse, abuse, failure to maintain, fair wear and tear or the replacement of serviceable items such as oil, spark plugs, air filters, fuel etc.

Our goods come with guarantees that cannot be excluded under Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Note: Units which are failing to perform in accordance with specifications due to non-warrantable causes will be subject to freight, repair and or quote charge